

- 005255-03
(2-Spd. Bezel)
- 005255-05
(3-Spd. Bezel)
- 005255-02
(4-Spd. Bezel)

78-16002
(Lubricant—
Not Shown)

NOTE
The shift bezel is not part of the gear shifter assembly and must be purchased separately.

A000610-02
(Handle)

- A000608-06 4-speed gear shifter assy. (uses 4 switches)
- A000608-07 3-speed gear shifter assy. (uses 3 switches)
- A000608-08 4-speed gear shifter assy. (uses 3 switches)
- A000608-09 2-speed gear shifter assy. (uses 2 switches)
- A000608-10 3-speed gear shifter assy. (uses 4 switches)

78-3002003
(Spring)

76-11375S
(Ball Bearing)

000609-02
(Housing)

65-021A
(Switch)

- 000611-02
("H" Detent)
- 005671-02
("N" Detent)
- 035792-01
(Strt. Detent)

035301-01
(Pin)

75-944S
(Hex Nut)

75-046
(Lock Washer)

72-1412S
(Screw)

85-22F608
(Screw)

**Gear-Shifter Assembly
A000608-06 thru -10 V**